#### **INSTALL BATTERIES**

#### **FIX ENCLOSURE**



### **INSTRUCTIONS FOR INSTALLING BATTERIES**

Batteries are provided in a separate pack and must be inserted into your enclosure before it is turned on. Insertion is easier if the enclosure is laid flat on its back.

- 1. Open the front cover.
- 2. Locate and remove the screws that hold down the battery cover.
- 3. Place the batteries back to back with the terminals facing outwards from each other.
- 4. Connect the interconnecting cable to the now bottom terminal on the left battery and the bottom terminal on the right battery. (i.e. the positive (red) terminal on the left battery and the negative (black) terminal on the right battery)
- 5. Locate the batteries in the base of the enclosure so that the terminals will be accessible via the clearance in the cover.
- 6. Connect the black cable to the top terminal (black) on one battery.
- 7. Connect the red cable (with the fuse holder) to the top terminal (red) on the other battery.
- 8. Ensure the connectors are securely located.
- 9. Replace the battery cover by inserting and tightening the holding screws.

## INSTRUCTIONS FOR FIXING THE ENCLOSURE

**DO NOT DRILL HOLES IN THE ENCLOSURE:** Your enclosure may be fixed to a wall by either of these methods:

- 1. For enclosures with clip fasteners: Included in the pack are mounting brackets that are able to be fitted to the rear corners of the enclosure.
- 2. For enclosures with screw down lid: In each corner of the enclosure are fixing holes located outside of the secure area. Fix using screws through these holes.

# Penetrating the enclosure will reduce its water resistance rating.